# CAE 208 / MMAE 320: Thermodynamics Fall 2023

# November 07, 2023 Intro to second law (2)

Built Environment Research @ IIT ] 😒 🚓 🍌 📢

Advancing energy, environmental, and sustainability research within the built environment

www.built-envi.com

Dr. Mohammad Heidarinejad, Ph.D., P.E. Civil, Architectural and Environmental Engineering Illinois Institute of Technology muh182@iit.edu

# ANNOUNCEMENTS

#### Announcements





# Architectural Engineering Panel

ASCE and ASHRA Co-Event: Panel to discuss many AE topics not covered at IIT

RE 104 | Wednesday 11-8 During Lunch |Food Will be Provided



#### Announcements

- The solution to Assignment 7 is posted
- Assignment 8 is posted
- Midterm exam 2 is this coming Thursday
- All students are responsible for their open book exam part
   No book / tables sharing will be allowed
   I will not bring any extra books


#### Announcements

• Watch the recordings if you need additional review time


	AE_208_MMAE_320.2024 0 (Thermodynamics)	Panopto Content
F	lome 🧧	
S	yllabus 🤤	Q Search in folder "CAE_208_MMAE_320.202410: Thermodynamics"
с	ontent 🤤	
A	ssignments 🤤	
C	Piscussions	CAE_208_MMAE_320.202410: Thermodynamics
c	ollaborate Ultra 🛛 🏾 🌚	Sort by: Name Duration Date - Rating
С	lass Recording   Panopto	
	•	+ Add folder
N	ly Grades 🛛 🧧	
E	mail 🤤	10/05/2023 Lecture14_Energy analysis of closed systems (2)
Ģ	ialvin Library 🛛 🚭	
т	ools 🛛 🔍	

# RECAP


- It is clear from these arguments that processes proceed in a certain direction and in the reverse direction
- The first law places no restriction on the direction of a process but satisfying the first law does not ensure that the process can actually occur



• Heat engines cycles are as following:




• The best example of a heat engine is the steam power plant:



# Recap

 The fraction of the heat input that is converted to net work output is a measure of the performance of a heat engine is called the *thermal efficiency*



 $Thermal \ efficiency = \frac{Net \ works \ output}{Total \ heat \ input}$ 

 The Second Law of Thermodynamics: Kelvin-Planck Statement:

It is impossible for any device that operates on a cycle to receive heat from a single reservoir and produce a net amount of work


No heat engine can have a thermal efficiency of 100 percent

For a power plant to operate, the working fluid must exchange heat with the environment as well as the furnace


# **REFRIGERATORS AND HEAT PUMPS**

- Refrigerators: The transfer of heat from a low-temperature medium to a high-temperature one requires special devices called refrigerators
- Refrigerators, like heat engines, are cyclic devices
- The working fluid used in the refrigeration cycle is called a refrigerant


 The most frequently used refrigeration cycle is the vaporcompression refrigeration cycle



 The most frequently used refrigeration cycle is the vaporcompression refrigeration cycle



• How many of you have seen the back of old refrigerators:



Side note: Are there any throttling valves around us in our campus?



- The efficiency of a refrigerator is expressed in terms of the coefficient of performance (COP)
- The objective of a refrigerator is to remove heat (Q<sub>L</sub>) from the refrigerated space


• COP of refrigeration is expressed as:

$$COP_R = \frac{Desired \ output}{Require \ input} = \frac{Q_L}{W_{net,in}}$$

$$COP_R = \frac{Q_L}{Q_H - Q_L} = \frac{1}{\frac{Q_H}{Q_L} - 1}$$

• Can the value of COP<sub>R</sub> be greater than unity?

 Heat Pumps: The objective of a heat pump is to maintain a heated space at high temperature. This is accomplished by absorbing heat from a low-temperature source, such as well water or cold outside air in winter and supplying this heat to the high-temperature medium as a house:



• *Heat pumps* are in the news right now:



 Heat Pumps – Our nation's buildings, homes, offices, schools, hospitals, military bases, and other critical facilities drive more than 40% of all U.S. energy consumption. To reduce the amount of energy needed in our buildings, leading to less reliance by the U.S. and allies on adversaries such as Russia for oil and gas, heat pumps are an important solution. Their use by the U.S. and allies can shrink Russian revenue for war and reduce climate instability. However, currently, U.S. HVAC manufacturers are not producing heat pumps at the rate needed. The Biden-Harris Administration can help American manufacturing expand and expedite the installation of heat pumps in homes and residential buildings by qualified building professionals.

 Heat Pumps: The objective of a heat pump is to supply heat Q<sub>H</sub> into the warmer space

$$COP_{HP} = \frac{Desired \ output}{Require \ input} = \frac{Q_H}{W_{net,in}}$$

$$COP_{HP} = \frac{Desired \ output}{Require \ input} = \frac{Q_H}{Q_H - Q_L}$$

$$COP_{HP} = \frac{Desired \ output}{Require \ input} = \frac{Q_H}{Q_H - Q_L}$$


Required input

net.in

Desired output

 Heat Pumps: The objective of a heat pump is to supply heat Q<sub>H</sub> into the warmer space

$$COP_{HP} = COP_R + 1$$



- Heat Pumps: The objective of a heat pump is to supply heat Q<sub>H</sub> into the warmer space
  - $\hfill \hfill \hfill$

□ What does COP<sub>HP</sub> represent?

- Performance of refrigerators, air conditioners, and heat pumps:
  - □ Most heat pumps have a seasonally averaged COP of 2 to 3
  - Most existing heat pumps use the cold outside air as the heat source in winter (air-source HP)
  - In cold climates their efficiency drops considerably when temperatures are below the freezing point
  - In such cases, geothermal (ground-source) HP that use the ground as the heat source can be used
  - Such heat pumps are more expensive to install, but they are also more efficient

- Performance of refrigerators, air conditioners, and heat pumps:
  - Air conditioners are basically refrigerators whose refrigerated space is a room or a building instead of the food compartment
  - The COP of a refrigerator decreases with decreasing refrigeration temperature
  - It is not economical to refrigerate to a lower temperature than needed

 Energy efficiency rating (EER): The amount of heat removed from the cooled space in Btu's for 1 W h (watthour) of electricity consumed

 $EER = 3.412 COP_R$ 

# **CLASS ACTIVITY**


# **Class Activity**

- The household refrigerator with a COP of 1.2 removes heat from the refrigerated space a rate of 60 kJ/min. Determine:
  - a) The electric power consumed by the refrigerator
  - b) The rate of heat transfer to the kitchen air

• Solution:

$$\dot{W}_{net,in} = \frac{\dot{Q}_L}{COP_R} = \frac{60 \ kJ/min}{1.2} = 50 \frac{kJ}{min} = 0.833 \ kW$$

$$\dot{Q}_H = \dot{Q}_L + \dot{W}_{net,in} = 60 + 50 = 110 \, kJ/min$$



# **CLASS ACTIVITY**

# **Class Activity**

- A heat pump is used to meet the heating requirements of a house and maintain it at 20 °C. On a day when the outdoor air temperature drops to -2°C, the house is estimated to lose heat at a rate of 80,000 kJ/h. If the heat pump under these conditions has a COP of 2.5, determine
  - a) The power consumed by heat pump
  - b) The rate at which heat is absorbed from the cold outdoor air

• Solution:

$$\dot{W}_{net,in} = \frac{\dot{Q}_{H}}{COP_{HP}} = \frac{80,000 \ kJ/h}{2.5} = 32,000 \ kJ/h \ (8.9 \ kW)$$

$$\dot{Q}_{L} = \dot{Q}_{L} - \dot{W}_{net,in} = (80,000 - 32,000) \frac{kJ}{h} = 48,000 \frac{kj}{h}$$

$$COP = 2.5$$

$$COP = 2.5$$

$$COP = 2.5$$

$$COP = 2.5$$

$$\dot{Q}_{L} = ?$$


• The Second Law of Thermodynamics: Clasius Statement

It is impossible to construct a device that operates in a cycle and produces no effect other than the transfer of heat from a lowertemperature body to a higher-temperature body.

- The Second Law of Thermodynamics: Clasius Statement
  - It states that a refrigerator cannot operate unless its compressor is driven by an external power source, such as an electric motor
  - This way, the net effect on the surroundings involves the consumption of some energy in the form of work, in addition to the transfer of heat from a colder body to a warmer one
  - To date, no experiment has been conducted that contradicts the second law, and this should be taken as sufficient proof of its validity

#### **Refrigerators and Heat Pumps**


The Second Law of Thermodynamics: Clasius Statement



A refrigerator that violates the Clausius statement of the second law.

#### **Refrigerators and Heat Pumps**

Equivalence of the Two Statements




Proof that the violation of the Kelvin–Planck statement leads to the violation of the Clausius statement.


#### **Refrigerators and Heat Pumps**

- Equivalence of the Two Statements
  - The Kelvin–Planck and the Clausius statements are equivalent in their consequences, and either statement can be used as the expression of the second law of thermodynamics
  - Any device that violates the Kelvin–Planck statement also violates the Clausius statement, and vice versa

# REVERSIBLE AND IRREVERSIBLE PROCESSES

- Reversible process: A process that can be reversed without leaving any trace on the surroundings
- Irreversible process: A process that is not reversible
- All the processes occurring in nature are irreversible







(b) Quasi-equilibrium expansion and compression of a gas

- Why are we interested in reversible processes?
  - 1) They are easy to analyze
  - 2) They serve as idealized models (theoretical limits) to which actual processes can be compared.
- Some processes are more irreversible than others
- We try to approximate reversible processes

 Reversible processes deliver the most and consume the least work





(a) Slow (reversible) process




(b) Fast (irreversible) process

 The factors that cause a process to be irreversible are called irreversibilities





(a) Fast compression




(b) Fast expansion




(c) Unrestrained expansion

- Irreversibilities includes
  - □ Friction
  - □ Unrestrained expansion
  - □ Mixing of two fluids
  - □ Heat transfer across a finite temperature difference
  - Electric resistance
  - □ Inelastic deformation of solids
  - Chemical reactions
- The presence of any of these effects renders a process irreversible

- Heat transfer through a temperature difference is irreversible
- The reverse process is impossible




(b) An impossible heat transfer process




(a) An irreversible heat transfer process

- Internally and Externally Reversible Processes:
  - Internally reversible process: If no irreversibilities occur within the boundaries of the system during the process (e.g., a quasi-equilibrium process)
  - Externally reversible: If no irreversibilities occur outside the system boundaries (e.g., heat transfer between reservoir and a system)






- Internally and Externally Reversible Processes:
   Totally reversible process: It involves no irreversibilities within the system or its surroundings
  - A totally reversible process involves no heat transfer through a finite temperature difference, no nonquasiequilibrium changes, and no friction or other dissipative effects.



# THE CARNOT CYCLE


# The Carnot Cycle

• Execution of the Carnot cycle in a closed system:




Reversible Isothermal Expansion (process 1-2,  $T_H$  = constant)

Reversible Adiabatic Expansion (process 2-3, temperature drops from  $T_H$  to  $T_L$ )




Reversible Isothermal Compression (process 3-4,  $T_L$  = constant)




Reversible Adiabatic Compression (process 4-1, temperature rises from  $T_L$  to  $T_H$ )

# The Carnot Cycle

The Reversed Carnot Cycle
 The Carnot heat-engine cycle is a totally reversible cycle
 Therefore, all the processes that comprise it can be reversed, in which case it becomes the Carnot refrigeration cycle






*P*-V diagram of the Carnot cycle

*P*-V diagram of the reversed Carnot cycle

# THE CARNOT PRINCIPLES


## **The Carnot Principles**

- Two main principles:
  - The efficiency of an irreversible heat engine is always less than the efficiency of a reversible one operating between the same two reservoirs
  - 2. The efficiencies of all reversible heat engines operating between the same two reservoirs are the same



#### **The Carnot Principles**


 All reversible heat engines operating between the same two reservoirs have the same efficiency (the second Carnot principle)



# THE THERMODYNAMIC TEMPERATURE SCALE


## The Thermodynamic Temperature Scale

- A temperature scale that is independent of the properties of the substances that are used to measure temperature is called a thermodynamic temperature scale
- Such a temperature scale offers great conveniences in thermodynamic calculations




## The Thermodynamic Temperature Scale

This temperature scale is called the Kelvin scale, and the temperatures on this scale are called absolute temperatures
 □ For reversible cycles, the heat transfer ratio Q<sub>H</sub>/Q<sub>L</sub> can be replaced by the absolute temperature ratio T<sub>H</sub>/T<sub>L</sub>



# The Thermodynamic Temperature Scale

This temperature scale is called the Kelvin scale, and the temperatures on this scale are called absolute temperatures
 A conceptual experimental setup to determine thermodynamic temperatures on the Kelvin scale by measuring heat transfers *Q<sub>H</sub>* and *Q<sub>L</sub>*.




$$T = 273.16 \frac{Q_H}{Q_L}$$

# THE CARNOT HEAT ENGINE

## **The Carnot Heat Engine**

 The Carnot heat engine is the most efficient of all heat engines operating between the same high- and lowtemperature reservoirs



• Any heat engine:

$$\eta_{th} = 1 - \frac{Q_L}{Q_H}$$

• Any Carnot heat engine:

$$\eta_{th,rev} = 1 - \frac{T_L}{T_H}$$

#### **The Carnot Heat Engine**


• We can say:

$$\eta_{th} = \begin{cases} < \eta_{th,rev} \\ = \eta_{th,rev} \\ > \eta_{th,rev} \end{cases}$$

irreversible heat engine reversible heat engine impossible heat engine

## **The Carnot Heat Engine**


 No heat engine can have a higher efficiency than a reversible heat engine operating between the same highand low-temperature reservoirs



# **CLASS ACTIVITY**

# **Class Activity**

- A Carnot heat engine receives 500 kJ of heat per cycle from a hightemperature source at 652 °C and rejects heat to a low-temperature sink at 30 °C. Determine:
  - a) A thermal efficiency of this Carnot engine
  - b) The amount of heat rejected to the sink per cycle




$$\eta_{th,rev} = 1 - \frac{T_L}{T_H} = 1 - \frac{30 + 273}{652 + 273} = 0.672$$

$$Q_{L,rev} = \frac{T_L}{T_H} Q_{H,rev} = \frac{30 + 273}{652 + 273} (500 \, kJ) = 164 \, kJ$$

## **The Carnot Heat Engine**


 The quality of Energy: The fraction of heat that can be converted to work as a function of source temperature (for T<sub>L</sub> = 303 K).



$$\eta_{th,rev} = 1 - \frac{T_{\rm L}}{T_{\rm H}}$$

# **The Carnot Heat Engine**

 The higher the temperature of the thermal energy, the higher its quality



# THE CARNOT REFRIGERATOR AND HEAT PUMP

• For any refrigerator or heat pump:

$$COP_R = \frac{1}{\frac{Q_H}{Q_L} - 1}$$


$$COP_{HP} = \frac{1}{1 - \frac{Q_L}{Q_H}}$$

• For any refrigerator or heat pump:

$$COP_{R.rev} = \frac{1}{\frac{T_H}{T_L} - 1}$$

$$COP_{HP,rev} = \frac{1}{1 - \frac{T_L}{T_H}}$$

 No refrigerator can have a higher COP than a reversible refrigerator operating between the same temperature limits.



- The COP of a reversible refrigerator or heat pump is the maximum theoretical value for the specified temperature limits
- Actual refrigerators or heat pumps may approach these values as their designs are improved, but they can never reach them

$$COP_{R} = \begin{cases} < COP_{R,rev} & irreversible refrigerator \\ = COP_{R,rev} & reversible refrigerator \\ > COP_{R,rev} & impossible refrigerator \end{cases}$$


- The COPs of both the refrigerators and the heat pumps decrease as  $T_{\rm L}$  decreases
- That is, it requires more work to absorb heat from lowertemperature media.

$$COP_{R} = \begin{cases} < COP_{R,rev} & irreversible refrigerator \\ = COP_{R,rev} & reversible refrigerator \\ > COP_{R,rev} & impossible refrigerator \end{cases}$$

# **CLASS ACTIVITY**

# **Class Activity**

 A Carnot refrigeration cycle is executed in a closed system in the saturated liquid-vapor mixture region using 0.8 kg of refrigerant 134-a as the working fluid. The maximum and the minimum temperatures in the cycle are 20 and -8  $^{\circ}$ C, respectively. It is known that the refrigerant is saturated at the end of the hat rejection process, and the net work input to the cycle is 15 kJ. Determine the fraction of the mass of the refrigerant that vaporizes during the heat addition process and the pressure at the end of the rejection process.



$$COP_R = \frac{1}{\frac{T_H}{T_L} - 1} = \frac{1}{\frac{20 + 273}{-8 + 273} - 1} = 9.464$$

$$Q_L = COP_R \times W_{in} = (9.464)(15 \, kJ) = 142 \, kJ \quad (The amount of cooling)$$


$$Q_{l} = m_{eva} h_{fg @ -8 °C} = \frac{142 \ kJ}{204.59 \frac{kJ}{kg}} = 0.694 \ kg \quad (Table \ A - 11)$$

 $Mass\ Fraction = \frac{m_{evap}}{m_{total}} = \frac{0.694\ kg}{0.8\ kg} = 0.868$ 

$$P_4 = P_{sat @ 20^{\circ}C} = 572.1 \, kPa$$

# **Class Activity**

 A heat pump is to be used during the winter. The house is to be maintained at 21 °C at all times. The house is estimated to be losing heat at a rate of 135,000 kJ/h when the outside temperature drops to -5 °C. Determine the minimum power required to drive this heat pump.



$$COP_{HP,rev} = \frac{1}{1 - T_L/T_H} = \frac{1}{1 - \frac{-5 + 273}{21 + 273}} = 11.3$$

$$\dot{W}_{net,in} = \frac{\dot{Q}_H}{COP_{HP}} = \frac{37.5 \ kW}{11.3} = 3.32 \ kW$$

